

## **Tips for Winterizing a Water Treatment System**

### **General Rules:**

- If Closed Loop Treatment System is inside climate controlled/insulated structure (Building or Conex) confirm thermostat is set and Heating system functions properly.
- If Closed Loop Treatment System is outside a climate controlled/insulated structure refer to the weather categories below.
- Add Heat Trace Tape to all exposed/at risk plumbing.
- Insulate all exposed/at risk plumbing with pipe insulation foam.

### **Potential Categories:**

- Light Freeze – Keep water circulating continuously. Drain pressure washer and water cannon hoses and any at risk piping.
- Heavy Freeze - Disconnect Sump Pump at Fernco and drain plumbing. Drain pressure washer and water cannon hoses and any at risk piping.
- Winterization – Drain Treatment System (including all pumps) and all exposed/at risk plumbing.